P 3123

Ultrasonic testing instrument for non-destructive hardness depth testing of heat-treated parts



QNET

Hardness Depth Testing of Heat-treated Parts

Non-destructive testing with ultrasonic backscattering technique,

portable testing system,

designed for tough industrial environment,


4-channel ultrasonic board,

Also suitable for testing of complex geometries e.g. crankshafts, gears, ...

optional automated testing.











Ultrasonic Backscattering Tequnique







System Components





Industry Notebook including:

- 4-Channel ultrasonic electronics
- Software SHD Studio
- Windows 7, 10
- DVD writer
- MIL-STD 810G, IP65, MIL-STD 461F certified
- W-LAN



Software SHD Studio





- Creation of testing programs and databases for parameter sets, transducers, materials, etc.
- Modules for routine testing, series testing, and signal analysis
- Real-time display of signals (A-scans), line-scans and real measuring point
- Automatic signal analysis and display of test results
- Automatic setting of zero point no range setting required



Industry Notebook and Hard Case



Industry Notebook



Case with foam interior



Coupling Wedges





Standard design: Flat, convex, concave

Custom design:Double sensors with housing



Accessories



Transducers 20 MHz, Diameters: 6 mm or 11 mm




Double-shielded transducer cables



USB pedal



Typical Inspection Geometries





Usage Examples



Hardness depth testing of heat-treated parts

such as:

- large-diameter slewing rings,
- crankshafts,
- tooth systems,
- spindles,
- axles arms,
- rolls,
- ... and many more



Usage Example: Large-diameter Slewing Rings













Testing the **pitch surfaces of the rolling element** (flat or curved), the **tooth flanks** and **bottom lands**




Usage Example: Crankshafts



Testing the flange / pins, journals and fillet radii



Usage Example: Testing of Fillet Radii





Usage Example: Testing of Tooth Systems










Testing of tooth systems: top and bottom lands and tooth flanks




Usage Example: Testing of Spindles and Threads





Usage Example: Testing of Fillets and Bearing Surfaces





Usage Example: Testing of tulips and shafts



QNET

Usage Example: Testing of Spline Shafts





Measurement on the top of splines



Usage Example: Wedge for Several Transducers



Wedge for 2 testing points



Usage Example: Handling Equipment



Semi-automated testing of crankshafts



Usage Example: Handling Equipment






Sensor units with housing




Validation



Measurement Positions on the crankshaft (main and pin journal, radius and middle of journal)



Wordwide Sales and Service



Sales word-wide: ~ 200



Clients (selected)











































































